



2211[®] SIGNATURE

RECHARGEABLE VARIABLE-OUTPUT LED WRISTLIGHT + WATCH

USER MANUAL



ANSI / FL 1 STANDARD

HIGH



OUTPUT



RUNTIME

MED



OUTPUT



RUNTIME

LOW



OUTPUT



RUNTIME



MAXVISION
BEAM™



RECHARGEABLE



FUEL GAUGE

2211[®] SIGNATURE

RECHARGEABLE VARIABLE-OUTPUT LED WRISTLIGHT + WATCH



Kit Contents:

- 2211 Signature Wristlight
- Micro-USB cable



**MICRO-USB
CHARGING PORT**

FUEL GAUGE



MaxVision Beam™ (MVB) is a smooth, broad light pattern perfect for close- to mid-range tasks

2211 SIGNATURE WRISTLIGHT + WATCH //

OUTPUT	High: 300 lumens Med: 60 lumens Low: 15 lumens
RUNTIME*	High: 1.0 hours Med: 4.0 hours Low: 13.0 hours
WEIGHT (w/battery)	3.75 oz (106 g)
SWITCHING	Ambidextrous pushbutton
DIMENSIONS	2.38" L x 2.02" W x 1.03" H (6.1 cm x 5.1 cm x 2.8 cm)
MATERIALS	Polymer body; nylon wristband
COLOR	Black
POWER SOURCE	Rechargeable lithium-ion battery

*All performance claims tested to ANSI/NEMA FL1-2009 Standard.

LIGHT ACTIVATION

High Output: Pressing either pushbutton switch once will activate the high output. Pressing either switch individually again after 0.5 seconds will turn the light off.

Medium Output: Pressing either pushbutton switch twice within 0.5 seconds will activate the high output and then the medium output. To turn the light off, press either switch again.

Low Output: Pressing either pushbutton switch three times within 0.5 seconds will activate the high output, medium output and then the low output. To turn the light off, press either switch again.

When using the WristLight with a handgun, When using the WristLight with a handgun, activate light—strapped to your support (non-gun) wrist—before drawing pistol from holster. Deactivate light after safely holstering pistol. Do not activate, deactivate, or adjust your 2211 Signature while holding a firearm.

PROGRAMMING THE 2211 SIGNATURE'S ACTIVATION SEQUENCE

The 2211 SIGNATURE'S default activation sequence goes from high to medium to low output and then off; however, it can also be programmed by the user to reverse this sequence—low-med-high-off—to accommodate personal preference. The 2211 Signature must be plugged into its charger to program the activation sequence. Once programmed and removed from its charger, the activation sequence will not change unless the 2211 Signature is reprogrammed to its default sequence.

To reverse the 2211 Signature's default activation sequence:

1. Plug 2211 Signature into its charger
2. Press and release one of the pushbuttons three times until low output is activated
3. Wait 5 or more seconds, then press one of the pushbuttons once more, turning the 2211 Signature off
4. Remove 2211 Signature from its charger and test activation sequence — it should now be low-med-high-off

To restore 2211 Signature' activation sequence to its default setting (high-med-low-off), repeat the above procedure with the following exception in Step #2: Press and release pushbutton three times until HIGH output is activated.

FUEL GAUGE

The 2211 Signature is equipped with an LED that lets you monitor the battery charge status, both during use and while charging. See FUEL GAUGE KEY for an explanation of the LED colors and their meanings.

FUEL GAUGE KEY



Full



Battery charge low.
Reduce output level
or recharge battery.



Empty. Recharge
battery immediately.

BATTERY CHARGING

The 2211 Signature is powered by an integral lithium-ion battery that will provide years of service, depending on use. The included micro-USB charger can be plugged into a wall socket, or, after removing the USB cable from the AC plug, into a USB port.

To charge the lithium-ion rechargeable battery:

1. Insert micro-USB charging plug into 2211 Signature charging port receptacle.
2. Insert wall charger plug into AC outlet, or USB plug into USB port of a computer or some other device that will provide power to the 2211 Signature.
3. When fuel gauge LED turns green, the light is charged to more than 90% of battery capacity.

NOTE: Charging a fully depleted battery can take up to three hours. The light may be left plugged into the charger without damaging the battery.

Do not attempt to remove or replace the 2211 Signature battery. Doing so will void the warranty. If battery needs repair or replacement, contact SureFire at **714-545-9444**.

WATCH OPERATION & CARE

Read the enclosed manual for instructions on how to operate and care for the watch movement of the 2211 Signature watch and WristLight.

The watch is powered by its own battery and can be replaced by a watchmaker following these steps:

1. Remove two Allen screws on top of 2211 Signature with a 5/64" hex key.
2. Remove two small set screws adjacent to crown using a 0.050" hex key and remove watch from WristLight body.
3. Carefully remove back plate of watch.
4. Replace spent battery with new one, 377 Silver Oxide.
5. Install back plate to watch.
6. Secure watch to body by reversing steps 1 and 2. **ADVISORY:** Limit tightening of top screws to finger tight then an additional 1/2 turn to keep from damaging the watch module.

BATTERY INFORMATION & WARNINGS

Before replacing batteries, read the enclosed BATTERY INFORMATION/WARNING insert in your original packaging. For additional battery safety, handling, and product information, visit www.surefire.com/batteries.

MAINTENANCE

Use a clean, dry cloth to wipe off body and window. For additional tips on maintaining your SureFire illumination tool, visit www.surefire.com/faqs-maintenance.

THE SUREFIRE NO-HASSLE GUARANTEE

We'll do what it takes to keep your SureFire gear running smoothly.

SureFire warrants that if you — our customer — purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it for free or refund your money — no hassle! There are just a few exceptions. For complete details, visit www.surefire.com/warranty.

WARRANTY CLAIMS

For claims, contact Customer Service at 714-545-9444 to obtain a Return Merchandise Authorization number (RMA#). Then package the unit carefully and send to (no CODs):

SureFire, LLC.
Repairs Department, RMA# _____
17680 Newhope Street, Suite B
Fountain Valley, CA 92708

SureFire will pay any reasonable shipping costs to return the unit to you.



18300 MT. BALDY CIRCLE
FOUNTAIN VALLEY, CA 92708-6122
WWW.SUREFIRE.COM

Patents: 9,155,168, 0758,628

Revision C 2-2018

71-01-995

2211-B-BK-SF

